



Tools Required




- 5/32 Hex Key (Included)
- #2 Square Drive Bit (Not Included)
- 1/2" Wrench (Not Included)

Hardware


- 2 - 5/16" x 3 1/2" Stainless Wafer Bolt
- 2 - 5/16" x 3" Stainless Wafer Bolts
- 6 - 5/16" x 2" Stainless Wafer Bolts
- 8 - 5/16" Nuts
- 12 - Washers
- 4 - 2" Screws
- 4 - 1 1/2" Screws
- 1 - Set Swing Chains
- 1 - 5/32" Hex Key

Parts List


- 2 - (A) Armrest Assemblies
- 1 - (B) Seat Assembly
- 1 - (C) Back Assembly




1. Attach (C) Back Assembly to (B) Seat Assembly using 6 - 2" Wafer Bolts, Be sure to match all numbers & or letters, Tighten with included Hex Key.





2. Attach Armrest Assemblies to each side using 1 - 3 1/2" Wafer Bolt 1 - 3" Wafer Bolt 2 - Washers & 2 Nuts per side. Tighten Bolts with included Hex Key. Insert Bolts from inside out:



3. Install 2 - 2" Screws & 2 - 1 1/2" Screws per side.



4. Attach short end of Chain to back of Armrest assemblies & other end through screw eye to bottom of front upright using 4 Washers & 2 nuts per side.



4' Plain Poly Swing Assembly Instructions

10/16/ 2017

R.M.